

Simeon Soundfield Quick Start Guide

A sound field is a portable device that amplifies a person's voice. A sound field is best used by presenter in a classroom or in presentations where audience members might be hard of hearing. The Simeon 500WU Duo model that the library has allows for two presenters to be able to broadcast over the sound system at once.

Contents of the Simeon Soundfield System

Please ensure contents of the Simeon Soundfield are kept together.

1. Speaker system in travel case
2. Speaker system AC power supply (not pictured, in a side pouch of travel case)
3. Hands free headset
4. Transmitter for use with hands free headset
5. Fabric belt with case for Transmitter
6. Wireless microphone
7. Charging station with AC power supply for Transmitter and Wireless microphone



Proper Use of Simeon Soundfield System

Note: At no point while using the Soundfield system is it necessary to remove the speaker from the carrying case that it is in. All switches are either visible through cut outs in the case or accessible with zippers.

1. Turn the Speaker system on. This can be done by flipping the switch in the bottom right corner on the rear of the speaker.



2. Turn on one or both of the receiver modules on the front of the speaker system using the volume knob. Each receiver module should be showing a different frequency channel. Ensure that the microphone system you are using is tuned to the channel on the receiver module.



3. Turn the microphone on.

To tune the microphone you are using to the appropriate channel, hold the 'Set' button on the transmitter or the small rectangular button on the black microphone until the display starts to flash. Use the directional arrow buttons to select the same channel as on the speaker system. Press the 'set' or small rectangular button again to save the channel.

If you need to change the channel on the receiver module it's done in the same way using the 'set' button.



Charging the Soundfield

1. Plug in the Soundfield AC power supply into the machine using the power jack on the rear of the speaker below the power switch.

Charging the Microphones

1. Plug the microphone or the hands-free transmitter into the charging dock. A red light will come on indicating that the device(s) are being charged.

Useful Tips

1. Wear the transmitter in the supplied belt pack. The belt pack is more secure than the belt clip and will protect the transmitter and delicate microphone from drop damage.
2. Keep the soundfield receiver away from classroom computers, which are sometimes a source of radio interference.
3. Avoid approaching very close to the Speaker system receiver with the microphone turned on- this may cause a squeal or feedback from the speaker.
4. If you have forgotten to charge the receiver/speaker system and the internal battery is low, it may be operated from the classroom AC supply via the charging power adapter.

If you need further help with use of the Simeon Soundfield please refer to the instruction manual located in the side pocket of the travel case or contact Patrick Miller.